

# CZ

DOSTUPNÉ FUNKCE		PŘÍKAZY AKTIVUJÍCÍ FUNKCI
AMAZON ALEXA	Zapnutí automatického úklidu	„Alexa, <b>turn on</b> <název>“ „Alexa, <b>start cleaning</b> on <název>“
	Vypnutí automatického úklidu	„Alexa, <b>turn off</b> <název>“ „Alexa, <b>stop cleaning</b> on <název >“
	Zvýšení a snížení hlasitosti	„Alexa, <b>set volume</b> of <název> to 10-100“ (lze nastavit 10, 20...100) „Alexa, <b>increase</b> (var. <b>decrease</b> ) volume of <název>“ (změna o 10 %)
MASTER 2 PRO (ETA6229) GOOGLE ASSISTANT	Zapnutí automatického úklidu	„Ok Google, <b>start</b> <název>“ „Ok Google, <b>start cleaning</b> on <název>“
	Vypnutí automatického úklidu	„Ok Google, <b>stop</b> <název>“ „Ok Google, <b>stop cleaning</b> on <název >“
	Najde robota v prostoru (zvuk)	„Ok Google, <b>find</b> <název>“ „Ok Google, <b>locate</b> <název>“
	Zvýšení a snížení hlasitosti	„Ok Google, <b>set volume</b> of <název> to 10-100“ (lze nastavit 10, 20...100) „Ok Google, <b>increase</b> (var. <b>decrease</b> ) volume of <název>“ (změna o 10 %)
	Sdělí % nabití akumulátoru	„Ok Google, <b>what's my battery</b> in <název>“ „Ok Google, <b>what's battery status</b> of <název>“
	Síla sání na 1/4	„Ok Google, <b>set the</b> <název> <b>to low</b> “
	Síla sání na 3/4	„Ok Google, <b>set the</b> <název> <b>to high</b> “
	Síla sání na 4/4	„Ok Google, <b>set the</b> <název> <b>to max</b> “
	Pauza	„Ok Google, <b>pause</b> <název>“
Obnovení úklidu	„Ok Google, <b>resume</b> <název>“	

# ENG

		AVAILABLE FUNCTIONS	COMMANDS ACTIVATING THE FUNCTION
AMAZON ALEXA	Switching on automatic cleaning		„Alexa, <b>turn on</b> <robot name>“ „Alexa, <b>start cleaning</b> on <robot name>“
	Switching off automatic cleaning		„Alexa, <b>turn off</b> <robot name>“ „Alexa, <b>stop cleaning</b> on <robot name >“
	Volume up and down		„Alexa, <b>set volume</b> of <robot name> to 10-100“ (can be set to 10, 20...100) „Alexa, <b>increase</b> (var. <b>decrease</b> ) volume of <robot name>“ (change of 10%)
MASTER 2 PRO (ETA6229) GOOGLE ASSISTANT	Switching on automatic cleaning		„Ok Google, <b>start</b> <robot name>“ „Ok Google, <b>start cleaning</b> on <robot name>“
	Switching off automatic cleaning		„Ok Google, <b>stop</b> <robot name>“ „Ok Google, <b>stop cleaning</b> on <robot name>“
	Finds the robot in the area (sound)		„Ok Google, <b>find</b> <robot name>“ „Ok Google, <b>locate</b> <robot name>“
	Volume up and down		„Ok Google, <b>set volume</b> of <robot name> to 10-100“ (can be set to 10, 20...100) „Ok Google, <b>increase</b> (var. <b>decrease</b> ) volume of <robot name>“ (change of 10%)
	Reports % battery charge		„Ok Google, <b>what's my battery</b> in <robot name>“ „Ok Google, <b>what's battery status</b> of <robot name>“
	Suction force at 1/4		„Ok Google, <b>set the</b> <robot name> <b>to low</b> “
	Suction force at 3/4		„Ok Google, <b>set the</b> <robot name> <b>to high</b> “
	Suction force at 4/4		„Ok Google, <b>set the</b> <robot name> <b>to max</b> “
	Pause		„Ok Google, <b>pause</b> <robot name>“
	Resume		„Ok Google, <b>resume</b> <robot name>“